



## HYPERLOW VERT FREE V2: FRAME ASSEMBLY GUIDE

The following are frame assembly instructions for the 15mm kit. Your build experience may differ slightly depending on your decision on whether or not to use the mounting shelves, or braces, or smaller standoffs.

Assemble arms with 4 x 12mm bolts



Slot battery plate onto top plate with 6 nylon nuts acting as spacers and 4 x 20mm bolts and 2 x 12mm as shown. *Make sure pressnuts are facing down.*



**Using 4 x 8mm bolts, install 2 x 10mm standoffs up front along with TPU cam mounts, and 4 x 15mm standoffs as shown. The slide TPU shelves over standoffs and mounting bolts**



**Add 4 x 8mm to secure the front and rear bottom plate sections to the rear four standoffs. Don't tighten all the way yet.**



Pay attention to arm orientation and slide them along with the 5mm carbon spacers into their mounting areas. The carbon spacer **MUST** be underneath the front arms if installing the front braces. Using 4 x 22mm bolts attach the arms and carbon locks to the body.



Insert middle section and secure with 4 x 22mm bolts.



