

HYPERLOW CINEMA CAMERA MOUNT ASSEMBLY



1. Reference picture above for orientations and attach the 4 right angle brackets to the underside of the top plate with 4 x 6mm flat head bolts.



2. Attach arms by sandwiching the middle brackets and securing with 2 x 8mm flathead bolts through to the m3 pressnut on the inside.



3. Attach aluminum bases to rear brackets with 2 x 6mm flathead bolts and 2 x m3 locknuts



4. Attach arms to bases with 2 x 12mm m4 bolts



5. Remove backing and stick on rubber pad

